2008 MITSUBISHI LANCER
TECHNICAL INFORMATION MANUAL

FOREWORD

This manual has been prepared as an introduction to the specifications, features, construction, functions, and other areas of the new 2008 LANCER.
It includes Technical Information and Body Repair Service. The Body Repair sections immediately follow Group 55 - Heater, Air Conditioning and Ventilation.

Please read this manual carefully so that it will be of assistance for your service and sales activities. Please note the following service manuals are also available and should be used in conjunction with this manual.

SERVICE MANUAL	MSCD-106B-2008
BODY REPAIR MANUAL	MSSP-406B-2008
PARTS CATALOG	BUM6Y108A_

MITSUBISHI MOTORS
North America Inc.

No part of this publication may be reproduced, stored in any retrieval system of transmitted, in any form or by any means, including but not limited to electronic, mechanical photocopying, recording or otherwise, without the prior written permission of Mitsubishi Motors Corporation.

©2007 Mitsubishi Motors Corporation
All Rights, Reserved
Printed in USA
MSSP-250B-2008

GROUP INDEX

General 00
Engine 11
Engine Lubrication 12
Fuel 13
Engine Cooling 14
Intake and Exhaust 15
Engine Electrical 16
Engine and Emission Control 17
Clutch 21
Manual Transaxle 22
CVT 23
Front Axle 26
Rear Axle 27
Wheel and Tire 31
Power Plant Mount 32
Front Suspension 33
Rear Suspension 34
Service Brakes 35
Parking Brakes 36
Power Steering 37
Body 42
Exterior 51
Interior and Supplemental Restraint System (SRS) 52
Chassis Electrical 54
Heater, Air Conditioning and Ventilation 55